

UW 10 UW 20 UW 100 UW 400

Canon:
IXUS.IXY 810IS/950IS/600/500/450
430/400/330/300a/300
Powershot S60 70/80/300/330/400/
410/ **A70** 75/80/85/95/100/200/300/
310/400/410/420/430/450/460/470/
850IS

Nikon:
Coolpix 2200/3200/3700/4100/4200/
4600/5200/5600/5900/7600/7900/
P1 2/3/4/60/L2/3/4/6/16/18

Samsung:
Kenox, Digimax V3 4/5/6/700/800/
A4 5/6/7/40/50/400/**D4** 5/6/7/103
V5 6/10/20/50/**Cyver** 410/X80
VLUUNV10 / NV8/20/15/
S85 800/1000

Olympus:
Camedia C-500Z/480Z/370/60Z/315
470Z/ **X-**450/350/550/1/2/3/**FE**120/
170/310/**m, Stylus**500/D-535/545/
800/595Z

FUJIFILM:
Finepix A-345/350/600/850/**F10Z**11
20/30/47/420/650/401Z/410Z/420Z/
31fd/40fd/45fd/50fd/E550/900Z

PENTAX:
Optio 30/60/330/430/330RS/430RS/
550/555/**E10** 20/30/X/**S40** 45/50/50/
55/60

HP:
Photosmart M307 407/437/527/537
R507 707/717

SONY:
Cybershot-DSC-P100 120/200/72/
92/**W100** 1/5/7/S800

KODAK:
Easysshare LS755 753/633
ONE/C663/C613/663 JOC L-108

SANYO:
Xacti VP C Mz31/S1 3/4

RICOH:
Caprio RZ1 R1/RR660/RR211/
RR630/GR-D/G3/3M/3S/4/4W

CASIO:
QVR 61/51/41/40/4/3
Exilim Z10 110/120

Konika Minolta:
Revio KD-200Z 300Z
Dimage 323

Kyocera:
Fine cam S3 / Yashica EZ
Digital 5030

Panasonic:
DMC LC33 43/LS1/80/LZ10/6/7/8

Andere:
Minox Dc8111
Rollei Prego DP 8300/6300/
5300/DT3200
Mach Power DX-550
Polaroid PDC3370
Praktica DCZ4.3
BenQ DCC40/C50
Toshiba Alegretto 3310

Canon:
IXUS.IXY 40/50/55/60/65/70/75/
80IS/85IS/90IS/400/430/500/700/
750/800IS/850IS/1000/900TI/
iZoom i5/i1/i1s/V2/V3
Powershot SD 200/300400/500/
550/600/630/650/700/800/900/
950IS/1000/2000IS

Nikon:
Coolpix S200 210/500/510/520/
550/600/700/L2/3/4/6/10/11/12/
14/15/16/18

Samsung:
Kenox, Digimax X70
L60 70/73/74w/77/700/NV10/11/20
24HD/S630/700/1000/1030/1050

Olympus:
Camedia C-170/180/470ZX-600/500
FE 5500/150/160/180/190/200/230/
300/320/330/340/350/**m, Stylus** 710/
740/750/760/300/400/410/780/600/
700/810/1000/1200/ **D-**630Z

FUJIFILM:
Finepix F 440/450Z/455Z/10Z/100fd/
11Z/20Z/30Z/40fd/460/47fd/470/480/
50fd/700/31fd/F31fd/A203/303/345Z/
350Z/400/500/J10/50/V10

PENTAX:
Optio 50/S5n/5z/6/7/S/4/10/12/4i/Si/
V/V1/30/40/45/50/55/60/**T10** 20/
30/60/**A10** 20/30/36/E40L36

SONY:
Cybershot-DSC-P100 120/200/10/
150/2/5/73/8/93/**W100** 130/150/170/
200/30/300/35/50/55/70/80/90/**N1**/
N2/F707/S650/700/750

KODAK:
Easysshare V530 550/803/1003

SANYO:
Xacti VP C AZ3/MZ3/S6

RICOH:
Caprio GR/R1I/X/X100/X8/R1 1v/2/
3/4/5/6/7/8/30/40/50/RR30/RR530

CASIO:
S100 500/600/600D/770/880/10
EXZ75 70/60/57/55/20/50/40/30/5/4/
3/500/200/600/700/750/1000/9/1050/
1200SR/10/100/1080/110/120/1200

Konika Minolta:
Revio KD-300z 400z/
Dimage E40 50/500/**F100** 200/
G400 500/530/600

Panasonic:
DMC Fx100 01/07/1/2/30/33/36/5/50/
520/55/7/8/9/**F1** 7/S20/S3/S5 LS2

Andere:
Rollei Prego DP4200
BenQ DC E53/520/510
Hitachi imaga HDC-531
Leica C-Lux 1

Canon:
IXUS.IXY
90/80/75/65/60/55/50/40/30/10
i/ii/iis/i5/i7zoom/lzoom/V3/V2/L/
L2/300/330/30a/200a/D320/S100/
S200/850IS/860IS/900IS/910IS/
IXY Wireless/**Powershot SD30**/
40/430/450/600/630/100/110/750/
800IS/870IS/1000/**S230** 200/110/
100/300/**A400** 450/460/550

Nikon:
Coolpix 3700/4100/4600/
S100 200/500/L10/11/12

Samsung:
Kenox, Digimax
U-CA5 4/3/X1/15wide/60/80
Q1/2/25wide/L50/L55W/
A55W 60/73/L74wide/L80/700/
A50W/S500 600/630/700/730/
830/850/1030/**VLUU** L730/830

Olympus:
Camedia FE-130/140/170/280/200/
210/220/230/240/250/270/280/290
C-315Z/310Z/**m, Stylus**10/15/20/25/
30/40/40digital/300/400/500/600/700/
780/800/820/830/**DigitalSMin**/
VerveS

FUJIFILM:
Finepix A340 330/310/303/203/700/
600/500/510/610/800/**F460** 470/480

PENTAX:
Optio M10 20/30/40/**E10** 20/40

SONY:
Cybershot-DSC-S40 S600/L1/**W30**/
35/40/50/55/70/80/90/100/200/
S500 650/700

KODAK:
Easysshare C763 743/653/643/533
Ls743/M853/873

SANYO:
Xacti VP C S60 7/6/4/3/1/E7

Kyocera:
Yashica EZ
Digital 5031

CASIO:
EXZ60 70/75/77

Panasonic:
DMC 07 10/12/30/33/50/55/**F1** 2/
LS2 1

Andere:
Toshiba Alegretto 3330
Hyundai DC-4300
Epson L-400/300
Leica C-Lux1/2

Canon:
Powershot SD
A10/20/30/40/50/60/70/75/80/85/95
510/520/530/540/550/560/570IS/580/590IS/
610/620/630/640/700/710IS/720IS/
S45/50/60/70/80

Nikon:
Coolpix 2000/2100/2200/3100/3200/4100/
4300/4800/5000/5100/5400/8400/885
P1 2/50/5000/5100/L1/5

Samsung:
Kenox, Digimax
360/370/420/430/530/**V50** V70
D60 370/430/470/510/530/610/3000/
3100/4000 **a5** 7/**UX4** Cyver300/400/**X85**

Olympus:
Camedia C1Z 2/40/70Z/350Z7460/7000/
5000Z/5500SZ/X-200/250/FE100/110
m, Stylus 500/D-353/545/595Z/
SP310/320/350

FUJIFILM:
Finepix Z600Z 2650/**A606** 610/820/900/
920/**F601Z** 610Z/**E500** 510/900/**M603**

PENTAX:
Optio S30 33L/33LF/330GS/555/230/750Z

HP:
Photosmart M517 636/735/812/935 **R817**

SONY:
Cybershot-DSC-P1 2/5/7/9/71/72/92
S60 90/75/85 **W1** 5/7/12/15 V1

KODAK:
Easysshare C300 310/330/340/360/653/663/
813/**X4300** 4200/**DX3215** 3500/3600/
3700/3900/4330/6340/6440/7440/7630/V1003/
1273/550Z/570Z/603/610/750Z/760L
Ls20 443/632/743/Z730/760

RICOH:
Caprio GX8/GX/RX G4 wide/RR30/
RR230/G600

CASIO:
Exilim-P700 600/XP700/QV5700

Panasonic:
DMC LZ1 2 LC80/70/50/20/5

Kyocera:
Fine cam L3 30/3v/4/4v/S4/3R/5R/3L

Konika Minolta:
Dimage F100 200/300/S304/404/414/E223
REVIO KD-3300

Andere:
Praktica DCZ4.4
Toshiba POR5300
PremireDc2302/3306/5330
Kenko Z510
BenQ DC 5330/S30
Kocom KDC-330
Hyundai HD-530
Hitachi HDC-331

